



# EPOXY PETROL TANK SEALANT

The ultimate cure against leaking and rusted tanks

## Manual

### EPOXY REMOVER

#### Application of Epoxy Remover

Epoxy Remover can be used to remove old layers of epoxy sealant on the inside of your steel petrol or oil tank. First remove all the petrol and rinse the tank with water. Thoroughly dry your tank and let it cool down completely before you put the remover in the tank.

Epoxy Remover will damage paint and tank gaskets. Therefore, wrap your tank in a plastic bag and tape around the filling opening. Tightly close the opening of the fuel tap. Make sure you also have a suitable seal for the filling opening of the tank.

Ensure good ventilation (outside air), gloves, protective clothing and safety goggles before opening the can of Epoxy Remover. Avoid breathing vapor. Pour the Epoxy Remover into the tank and close the filling opening. Shake the tank gently for a few seconds to ensure the Epoxy Remover spreads throughout the tank. Then open the filling opening briefly to allow any excess pressure to escape. Don't forget your safety goggles and gloves.

**Never** place your tank filled with Epoxy Remover in direct sunlight, but in a cool and well-ventilated place. Leave the Epoxy Remover in the tank for a day, after which you drain the remainder (outside!). The old epoxy coating in your tank will come out in small flakes. Rinse the tank with plenty of water. Before applying a new layer of coating, clean the tank thoroughly with Tank Cure Cleaner and treat it with the Tank Cure Rust Remover.

#### Important instructions for the use of Epoxy Remover:

- Epoxy Remover may only be used in steel tanks.
- Definitely do not use in plastic tanks (chemical reaction)
- Never pour Epoxy Remover into a heated tank.
- Do not store in the sun or near heat sources.
- Keep away from heat/sparks/open flames hot surfaces. Do not smoke.
- Do not use Epoxy Remover in combination with other substances.
- Do not use Epoxy Remover in tanks with petrol or oil residue.
- It is recommended to work with Epoxy Remover outdoors.
- After using the remover ALWAYS rinse the tank thoroughly with water and Tank Cure Cleaner
- Only use rust remover (acid) after the tank has been rinsed with water and with Tank Cure Cleaner
- Do not expose tank to high temperatures when using Epoxy Remover.

#### Storage

- Store in a well closed container in a well-ventilated and cool place. Keep away from sources of ignition.
- Do not store in the sun or near heat sources.
- Keep out of reach of children.
- Dispose of residues as chemical waste.

V160223

#### Disclaimer

The data in this sheet is based on years of product development and practical experience and is correct on the day of issue. Nevertheless, Poly-Service BV cannot accept any liability for the work produced according to this information, as the result is partly determined by factors that are beyond our responsibility and influence. Poly-Service BV reserves the right to make changes to this sheet without notice. This product sheet supersedes all previous editions.